

[c o r k s p o r t]



Installation instructions for the CorkSport 'Type CS' Series 4 Rx7 Front Lip

TOOLS

- 8mm wrench or socket
- Floor Jack
- Two 8 inch sections of double sided tape
- Philips screwdriver
- Two jack stands

CONTENTS

- 1 Type CS FRP Lip Spoiler
- 3 Page Install Instructions

NOTE: At CorkSport, we try to make parts that require little or no modifications to the part to install. However, when working with vehicles of this age it is common to experience some differences in fitment between vehicles. For that reason, some trimming may be required to the part for it to fit correctly to your vehicle.

NOTE: Before you start test fit the lip on your car. Make sure the lip fits snugly on the back corners of the wheel well on the bumper. You may need to sand or file the back side of the lip to get the contour to fit properly.

NOTE: The front of your car will be lower. Take care when pulling into parking spaces with curbs, steep driveways, and avoid road debris.

DANGER: Follow instructions that came with your jack/stands. Death and or significant property damage could result if you do not.

Step 1: Jack up the front of vehicle and place securely on jack stands.

Step 2: Remove the 17 8mm/Phillips head screws holding on the factory lower lip.



Step 3: Apply the two sections of double sided tape on the inside edge of the lip on the left and right corner of the bumper. Leave the red film on the tape for now.



Step 4: Using 2 of the previously removed screws, attach the new lip at the 2 mounting brackets on the ends, up to the fender of the car. Leave somewhat loose at this time.



Step 5: Position the lip up onto the bumper and using 2 more of the original screws, attach the 2 inner mounting brackets to the bumper.



Step 6: Peel the backing from the double sided tape and press against the bumper.

Step 7: Go back and tighten all 4 screws.

Step 8: Remove vehicle from jack stands.

Install complete, enjoy!