

CorkSport

MAZDA PERFORMANCE



CorkSport 2001-2003 Protégé Eyelids Install Instructions

Tools Required

- Rubbing alcohol and a clean rag

Contents

- CorkSport Eyelids, (left and right)
- 3M Double Sided Tape (preattached)
- 2 Page Installation Instructions

At CorkSport, we strive to give you good quality no hassle parts, however, with fiberglass there are many factors that we can not prepare for to make this part fit properly on your vehicle. We recommend that you fit the part to your vehicle and do any modifications needed to make the part fit properly prior to final prepping and painting of part.

Please call 360 260 CORK if you have any questions about the installation of this product

Step 1: Open your hood and set the eyelids loose on top of the headlights. Note the location where the eyelids cover the headlights.

NOTE: You probably want these painted before proceeding.

Step 2: Remove the eyelids and clean the contact area of the eye lids with the rubbing alcohol to make sure there are no oils present which would affect the ability of the 3m adhesive to properly secure.

Step 3: Remove the red backing from the 3m tape and press the eyelids against the headlight. Make sure to press the eyelid so it sits securely against the headlight. Repeat installation for the other side.



Step 4: Enjoy the new look of your Protégé.

Please call 360 260 CORK if you have any questions about the installation of this product