

CorkSport

MAZDA PERFORMANCE



Installation Instructions for the CorkSport 99-05.3 Protégé Cooling Panel

Parts

- CorkSport Cooling Panel
- 10mm nuts x4
- 10mm bolt
- Bonded washer x3

Tools required

- 10mm Wrench
- Pliers

The CorkSport Protégé Cooling Panel can be installed with or without painting, it looks good either way. If you are painting the panel your self make sure you give it enough time for the paint to dry/cure before installation.

WARNING! Make sure your car is cool before installation begins.

Step 1: Open your hood.

Step 2: Remove the 10mm headed bolt marked '1' in Illustration #1

Step 3: Loosen the four 10mm headed nuts marked '2' in Illustration #1. You need the radiator support brackets to be a little loose.

Step 4: Remove the radiator cap marked '3' in Illustration #1

Step 5: Remove the two 10mm headed nuts marked '4' in Illustration #1 and thread them on upside down half way down the studs on the radiator support brackets.

Step 6: Using the pliers rotate the hose clamp on the upper radiator hose so the two tabs face towards the drivers side of the car.

Step 7: Install the 10mm bolt with the last bonded washer through the hole on the radiator panel marked '2' on Illustration #2. Install the two 10mm nut onto the 10mm bolt on the other

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

side of the radiator panel. You want the nuts to be about an inch from the top of the nut and the bolt loose in the panel.

Step 8: Install the new CorkSport Radiator panel into your car. You may have to move the upper radiator mounting brackets to center the holes in the panel.

Step 9: Adjust the height of the two upside down 10mm nuts on radiator brackets to get the radiator panel level with the radiator support. When the radiator panel is level use two of the 10mm nuts and the two bonded washers provided to tighten down on top of the radiator panel marked '1' in Illustration #2.

Step 10: Tighten down the 10mm bolt in step 7 until the washer and bolt head touch the top of the radiator panel. Tighten down the bottom nut on the bolt until it is snug against the radiator. Tighten the upper 10mm nut until it is tight against the back side of the radiator panel.

Step 11: Tighten down the four 10mm headed nuts on the radiator support brackets marked '3' in Illustration #2. Re-install your radiator cap.

Step 12: Take a soft clean rag and wipe away the finger prints. You are all done!

Illustration #1



Illustration #2



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK